

Tabulka 4 - pokračování

Úsek	Technický normativ hmotnosti v tunách pro lokomotivu řady						Poznámky
	731	740	752.6	2 x 731	2 x 740	2 x 752.6	
		741	753.7		2 x 741	2 x 753.7	
	742	754		2 x 742	2 x 754		
Trať: Veselí nad Moravou - Brno-Maloměřice a zpět							
Veselí nad Moravou - Nemotice	T <sub>4</sub> 940	T <sub>4</sub> 1100	T <sub>4</sub> 1200	T <sub>4</sub> 1780	T <sub>4</sub> 2100	T <sub>4</sub> 2300	
	T 910	T 1080	T 1150	T 1720	T 2060	T 2200	
	S 890	S 950	S 1100	S 1680	S 1800	S 2100	
Nemotice - - Blažovice	T <sub>4</sub> 570	T <sub>4</sub> 640	T <sub>4</sub> 740	T <sub>4</sub> 1040	T <sub>4</sub> 1200	T <sub>4</sub> 1400	
	T 560	T 620	T 700	T 1020	T 1200	T 1300	
	S 550	S 610	S 670	S 1000	S 1200	S 1200	
Blažovice - - Brno-Slatina	T <sub>4</sub> 650	T <sub>4</sub> 680	T <sub>4</sub> 700	T <sub>4</sub> 1080	T <sub>4</sub> 1260	T <sub>4</sub> 1300	
	T 620	T 660	T 680	T 1040	T 1220	T 1260	
	S 600	S 650	S 670	S 1000	S 1200	S 1200	
Brno-Slatina - - Brno-Maloměřice	T <sub>4</sub> 1200	T <sub>4</sub> 1250	T <sub>4</sub> 1250	T <sub>4</sub> 2300	T <sub>4</sub> 2400	T <sub>4</sub> 2400	
	T 1130	T 1200	T 1200	T 2160	T 2300	T 2300	
	S 1000	S 1150	S 1150	S 1900	S 2200	S 2200	
Brno-Maloměřice - - Brno-Slatina	T <sub>4</sub> 670	T <sub>4</sub> 750	T <sub>4</sub> 850	T <sub>4</sub> 1240	T <sub>4</sub> 1400	T <sub>4</sub> 1600	
	T 650	T 730	T 800	T 1220	T 1360	T 1500	
	S 650	S 700	S 750	S 1200	S 1300	S 1400	
Brno-Slatina - - Blažovice	T <sub>4</sub> 720	T <sub>4</sub> 850	T <sub>4</sub> 870	T <sub>4</sub> 1340	T <sub>4</sub> 1600	T <sub>4</sub> 1640	Při rozjezdu v úseku Kyjov - Vlkoš platí:
	T 710	T 820	T 840	T 1320	T 1540	T 1580	
	S 650	S 800	S 820	S 1300	S 1500	S 1540	
Blažovice - - Nemotice	T <sub>4</sub> 670	T <sub>4</sub> 800	T <sub>4</sub> 870	T <sub>4</sub> 1240	T <sub>4</sub> 1500	T <sub>4</sub> 1640	♦ T <sub>4</sub> 1030
	T 650	T 760	T 850	T 1220	T 1420	T 1600	♦ T 980
	S 630	S 750	S 800	S 1200	S 1400	S 1500	♦ S 970
Nemotice - Veselí nad Moravou	T <sub>4</sub> 850	T <sub>4</sub> 1020	T <sub>4</sub> 1150♦	T <sub>4</sub> 1600	T <sub>4</sub> 2000	T <sub>4</sub> 2200◊	◊ T <sub>4</sub> 1960
	T 820	T 970	T 1100♦	T 1540	T 1840	T 2100◊	◊ T 1860
	S 800	S 950	S 1000♦	S 1500	S 1800	S 1900◊	S 1840
Trať: Vrbovce - Veselí nad Moravou a zpět							
Vrbovce - Veselí nad Moravou		S 1300			S 2500		
Veselí nad Moravou - Vrbovce		S 500			S 900		
Trať: Veselí nad Moravou - Rohatec (- Hodonín) a zpět							
Veselí nad Moravou - Sudoměřice		S 1200					
Sudoměřice - - Rohatec		S 550					
Rohatec - Hodonín		S 1600					
Hodonín - Rohatec		S 1600					
Rohatec - - Sudoměřice		S 600					
Sudoměřice - Veselí nad Moravou		S 1200					